

Cross references

Discontinued Products

Discontinued product:	Replaced by:
2002 - Temperature pressure transmitter	2202 - R/I transmitter
2007 - Shaft speed monitor	2255 - f/l -f/f converter
2020 - Power supply	2220 - Switchmode power supply
2033 - Pressure transmitter	No replacement
2038 - Double limit switch	2238 - Dual trip amplifier
2060 - Pressure transmitter	2261 - mv - transmitter
2103 - 2-wire transmitter	2273 - 2-wire R/I transmitter
2110 - 3-term controller	2286 - Signal controller
2120 - Shaft speed monitor	2255 - f/l -f/f converter
2123 - Shaft speed monitor	2255 - f/l -f/f converter
2179 - Isolation amplifier	2204 - Isolation amplifier
2202P - Current simulator	2289 - Signal calculator
2203 - 2-wire transmitter	2273 - 2-wire R/I transmitter
2205 - Pi regulator	2289 - Signal calculator
2206 - Man/auto regulator	2289 - Signal calculator
2207 - Pi on/off regulator	2286 - Signal controller
2208 - Programmable pulse calculator	2255 - Programmable f/l converter
2209 - 3-band controller	2286 - Signal regulator
2210 - l/f converter	5222 - Programmable l/f converter
2211A - Analog calculator	2289 - Signal calculator
2211B - Analog calculator	2289 - Signal calculator
2212 - f/l converter	2255 - Programmable f/l converter
2213 - Analog indicator	No replacement
2214 - Hold/peak/delay transmitter	2289 - Signal calculator
2215 - Tacho switch	5225 - Prog. f/l-f/f converter
2215 - Tacho switch	2255 - f/l-f/f converter
2216 - Programmable amplifier	2284 - Isolation amplifier
2217 - Ramp generator	2281 - Ramp generator
2218 - C/I transmitter	No replacement
2219 - Analog comparator	No replacement
2221 - Switchmode power supply	2220 - Switchmode power supply
2225 - Valve driver	No replacement
2226 - Signal controller power supply	No replacement
2227 - DC/DC converter	No replacement
2228 - Switchmode boost power supply	No replacement
2230 - Current limiter	2289 - Signal calculator
2232 - Dual trip amplifier	2231 - Trip amplifier
2233 - Limit switch	2231 - Trip amplifier
2234 - Limit switch	2231 - Trip amplifier
2235 - Limit switch	2231 - Trip amplifier
2236 - Limit switch	2231 - Trip amplifier
2239 - Power supply	2229 - Switchmode voltage. regulator
2242 - Programmable timer	No replacement
2244 - Universal timer	No replacement

2246 - Level controller	No replacement
2252 - Frequency relay	2255 - f/i-f/f converter
2253 - Programmable f/l converter	2255 - f/i-f/f converter
2254 - Programmable l/f converter	5222 - Programmable l/f converter
2260 - mV transmitter	2261 - mV transmitter
2262 - mV transmitter	2261 - mV transmitter
2263 - Square root extractor	2289 - Signal calculator
2272 - R/I transmitter / limit switch	2271 - R/I transmitter / Trip amplifier
2274 - Isolated R/I transmitter	5114_1 - Programmable transmitter
2276 - Termocouple transmitter	5114_1 - Programmable transmitter
2277 - Termocouple transmitter	5114_1 - Programmable transmitter
2278 - AC/DC transmitter	2279 - AC/DC transmitter
2287 - Pi step regulator	2286 - Signal calculator
2290 - Analog mini micro processor system	No replacement
2292 - Analog mini micro processor system	2255 - f/i-f/f converter
2294 - l/l converter	5114_1 / 2289 - Program. trans. / sig. calculator
2295 - Ramp generator	2281 - Ramp generator
2354 - Energy meter	No replacement
2359 - Mini micro processor system	No replacement
2366A - 3 ½ digit LCD indicator	No replacement
2366B - 3 ½ digit LCD indicator	5515 - Indicator 48x96 mm
2388 - 4 ½ digit LCD indicator	5511 - Universal indicator
2402 - R/I transmitter	No replacement
2404 - Isolation amplifier	No replacement
2409 - 3-term controller	No replacement
2411 - Analog calculator	No replacement
2412 - f/l converter	No replacement
2438 - Dual limit switch	No replacement
2460 - P/I transmitter	No replacement
2462 - Power supply	No replacement
2500 - Eurocard	No replacement
2503 - Process calculator	No replacement
2536 - Limit switch	No replacement
2555 - Current / voltage supply	No replacement
2556 - Power supply	No replacement
2557 - mA/V-meter	No replacement
2572 - Transmitter with limit switch	No replacement
2574 - Transmitter	No replacement
2584 - Isolation amplifier	No replacement
2704 - Isolation amplifier	2284 / 2204 - Isolation amplifier
2755 - 3 ½ digit LED indicator	5515 - Indicator 48x96 mm
2766 - 3 ½ digit LED indicator	5515 - Indicator 48x96 mm
2788 - 4 ½ digit LED indicator	5511 - Universal indicator
2800 - PLC interface series (2801, 2802, 2803)	No replacement
2801 - PC interface analog I/O	No replacement
2802 - PC interface digital I/O	No replacement
2803 - PC interface analog I/O	No replacement
2810 - A/D interface	No replacement
2811 - D/A interface	No replacement

2820 - Opto terminal block	No replacement
2885 - RS232/RS485 transmitter	No replacement
2910 - 2-wire TC transmitter	5331 - 2-wire program. transmitter
2911 - 2-wire PT100 transmitter	5331 - 2-wire program. transmitter
2912 - 2-wire R/I transmitter	5131 - 2-wire program. transmitter
2921_1 - Ex-isolation amplifier	5104 - Ex-repeater / power supply
2921_2 - Ex-isolation amplifier	5105B - Ex isolated driver
2922_2 - Ex-isolation amplifier	5104 - Ex-repeater / power supply
2924 - Prog. isolation amplifier	5114_2 - Programmable transmitter
2931 - Ex-power supply	5420B - Ex power supply
2966_2 - Loop powered LCD indicator	5531 - 4-20 mA LCD indicator
2966_3 - Loop powered LCD indicator	No replacement
3400 - Energy meter system	No replacement
3401 - Energy meter	No replacement
3500 - PID regulator	No replacement
3533 - One to two isolation amplifier	No replacement
3534 - R/I transmitter	5102 - RTD transmitter
3535 - f/I converter	5225 - Program. f/I - f/f converter
4000 - PID regulator	No replacement
5114 - Old versions	5114 - New versions
5131 - Old versions	5131 - New versions
5132B - 2-wire transmitter	5104 - Ex-repeater / power supply
5201 - 2-channel pulse isolator	5202 - 2-channel pulse isolator
5211 - Isolated pulse amplifier	No replacement
5512 - Universal panel meter	No replacement
5905 - Loop link - Ex/standard	5905A - Loop link - standard (No ex-approval)